



**INSTALLATION INSTRUCTIONS
AFFIX OPERATING INSTRUCTIONS DECAL
S-SERIES/K-SERIES TRANSIT & TRANSIT-STANDEE
WHEELCHAIR LIFTS**

- Be certain these supplemental instructions are read and understood completely before installation is attempted. You should also refer to Service/Owner Manual for additional installation instructions and safety precautions.
- Check contents of this kit and notify Ricon immediately of any missing parts. Claims for damages or shortages that have occurred during shipping must be made to freight carrier.

TABLE OF CONTENTS

I. IMPORTANT.....	1
II. INSTRUCTIONS.....	1

I. IMPORTANT

- One of the **most important** steps in the S-Series/K-Series lift installation is to properly affix the operating instruction decal to the vehicle in an area where it is clearly visible to the lift operator **and** where it will not be damaged.
- The lift should not be put into use until this operating instruction decal has been affixed according to the following instructions:

II. INSTRUCTIONS

S-SERIES/K-SERIES TRANSIT AND TRANSIT-STANDEE WHEELCHAIR LIFTS (DECALS 26230/26231):

1. Select a smooth, clean and flat area to apply the lift operating instructions decal. The decal must be located where it will be clearly visible to the operator of the lift. The mounting surface must be clean and dry to ensure permanent adhesion. Choose a metal or hard plastic area.
2. Peel backing from decal.
3. Press decal onto the selected surface, and smooth out any wrinkles and/or trapped air bubbles.