



**INSTALLATION INSTRUCTIONS  
KIT, SHIM, S-SERIES #01228**

- Be certain that these supplemental instructions are read and understood completely before installation is attempted. You should also refer to the Service/Owner Manual for additional installation instructions and safety precautions.
  
- Check contents of this kit and notify Ricon immediately of any missing parts. Claims for damages that have occurred during shipping must be made to the shipper.

<b>TABLE OF CONTENTS</b>	<b>PAGE</b>
I. INTRODUCTION .....	1
II. INSTALLATION .....	1

**I. INTRODUCTION**

The following instructions outline the placement of shims under the front of the base plate.

## II. INSTALLATION

- A. Insert the two supplied shims under the front of the base plate and align shim holes with those of the base plate.
- B. Insert bolts through base plate, shims and vehicle floor and finger tight them.
- C. Insert the supplied spacer under the front center of the base plate and align both holes.
- D. Tighten all bolts.

