

RICON authorized service technicians must install and service this RICON product.

Operator must refer to this manual for operating instructions, and retain it for future reference by authorized service technicians.

Customer Name: _____

Installing Dealer: _____

Date Installed: _____

Serial Number: _____

REVISION RECORD

REVISION	PAGES	DESCRIPTION	ECR/ECO
32DER601. B	1-1	Updated illustration to show most current version of 1:6 ramp.	6461
	2-1	Updated illustration to show most current version of 1:6 ramp.	
	2-2	Revised Table 2-1 with most current configuration.	
	2-3	Update Figure 2-2.	
	2-4	Revised Table 2-2.	
	3-5	Removed reference to stow-lock. Updated Figure 3-4.	
	4-2	Updated Figure 4-1.	

TABLE OF CONTENTS

<u>Chapter</u>	<u>Page</u>
I. FOLDOVER 1:6 RAMP INTRODUCTION	1-1
RICON PRODUCT SUPPORT	1-1
RICON TWO-YEAR LIMITED WARRANTY.....	1-1
SHIPPING INFORMATION.....	1-3
GENERAL SAFETY PRECAUTIONS	1-3
II. FOLDOVER 1:6 RAMP DESCRIPTION	2-1
A. RAMP FEATURES	2-1
1. INTERLOCK SUPPORT	2-1
2. AUDIBLE ALERT	2-1
3. RAMP CONTROL PANEL	2-1
B. EXPLANATION OF RAMP PART NUMBERS	2-2
C. MAJOR COMPONENT DESCRIPTIONS	2-3
III. FOLDOVER 1:6 RAMP OPERATING INSTRUCTIONS.....	3-1
A. SAFETY PRECAUTIONS	3-1
B. DAILY INSPECTION.....	3-2
C. RAMP OPERATION	3-2
1. OPERATING RAMP WITH CONTROL PANEL.....	3-3
2. OPERATING RAMP MANUALLY	3-5
IV. FOLDOVER 1:6 RAMP MAINTENANCE	4-1
A. MAINTENANCE SCHEDULE	4-1
B. RAMP DECALS	4-2

This page intentionally left blank.