

FOLDOVER RAMP a
Low-Floor Vehicle
Access Ramp
for
GILLIG

TABLE OF CONTENTS

Print Entire Manual (290K)

OPERATOR MANUAL

32DFR103.A



08/27/99

ã 95-2002 RICON CORPORATION

RIC	S RICON PRODUCT MUST BE SERVICED BY AUTHORIZ ON SERVICE TECHNICIANS.
	DDUCT USERS MUST REFER TO THIS MANUAL FOR EXAMINE AND GENERAL MAINTENANCE INSTRUCTIONS
	TAIN THIS MANUAL IN THE VEHICLE FOR FUTU TERENCE.
	Customer Name:
	Customer Name: Installing Dealer:
	Installing Dealer:

REVISION RECORD

REVISION	PAGE(S)	DESCRIPTION OF CHANGE	ECR/ECO
32DFR103.A	ALL	Initial Release	N/A

TABLE OF CONTENTS

<u>Chapt</u>	<u>er</u>	1	<u>Page</u>
l.	INT	RODUCTION	. 1-1
	RICC	ON ONE-YEAR LIMITED WARRANTY	. 1-2
II.	DES	SCRIPTION	. 2-1
	A.	RAMP FEATURES	. 2-1
	B.	RAMP LOAD CLEARANCE AND CAPACITY	. 2-2
	C.	MAJOR COMPONENTS	. 2-2
	D.	RAMP DECALS	. 2-4
III.	OPE	ERATING INSTRUCTIONS	. 3-1
	A.	SAFETY PRECAUTIONS	. 3-1
	B.	DAILY INSPECTION.	. 3-2
	C.	RAMP OPERATION	. 3-3
IV.	MAI	INTENANCE INSTRUCTIONS	. 4-1