


# **RICON**®

*INNOVATION IN MOBILITY™*

## **PSL-20 TRANSIT USE WHEELCHAIR STEP-LIFT**

[PRINT ENTIRE MANUAL](#)

[TABLE OF CONTENTS](#)



### **SERVICE MANUAL**

12/12/03

32DSL104.B

© 1995-2003 RICON CORPORATION  
All Rights Reserved

U.S. Patent No. 5,425,615  
Other U.S. and foreign patents pending.  
Printed in the United States of America

**This Ricon service manual is for use by qualified service technicians, and is not intended for use by non-professionals (do-it-yourselfers). The manual provides essential instructions and reference information, which supports qualified technicians in the correct installation and maintenance of Ricon products.**

**Qualified service technicians have the training and knowledge to perform maintenance work properly and safely. For the location of a Ricon authorized service technician in your area, call Ricon Product Support at 1-800-322-2884.**

## REVISION RECORD

Rev	Pages	Description Of Change	ECR/ ECO
32DSL104. A	NA	New release.	NA
END OF TABLE			

## TABLE OF CONTENTS

<i>Chapter and section</i>	<i>Page</i>
<b>STEP LIFT INTRODUCTION .....</b>	<b>1-1</b>
<b>RICON SERVICE SUPPORT .....</b>	<b>1-1</b>
<b>WARRANTY INFORMATION .....</b>	<b>1-1</b>
<b>SHIPMENT INFORMATION .....</b>	<b>1-3</b>
<b>GENERAL SAFETY PRECAUTIONS .....</b>	<b>1-3</b>
<b>STEP LIFT DESCRIPTION .....</b>	<b>2-1</b>
<b>STEP-LIFT MOTIONS AND POSITIONS .....</b>	<b>2-1</b>
<b>MAJOR STEP LIFT COMPONENTS .....</b>	<b>2-2</b>
<b>STEP LIFT CONTROLS .....</b>	<b>2-4</b>
<b>CONTROL PANEL .....</b>	<b>2-4</b>
<b>MANUAL BACK-UP SYSTEM .....</b>	<b>2-5</b>
<b>STEP LIFT MAINTENANCE .....</b>	<b>3-1</b>
<b>MAINTENANCE SCHEDULE .....</b>	<b>3-1</b>
<b>TO DETERMINE MAINTENANCE INTERVAL .....</b>	<b>3-1</b>
<b>MAINTENANCE INTERVAL CHARTS .....</b>	<b>3-1</b>
<b>MAINTENANCE CHECKLIST .....</b>	<b>3-2</b>
<b>HYDRAULIC SYSTEM DIAGRAM .....</b>	<b>3-4</b>
<b>ELECTRICAL DIAGRAM .....</b>	<b>3-5</b>
<b>DIAGRAM LEGENDS.....</b>	<b>3-5</b>
<b>ELECTRICAL DIAGRAM .....</b>	<b>3-7</b>
<b>STEP LIFT SPARE PARTS .....</b>	<b>4-1</b>
<b>FIGURE 4-1: DECAL PART NUMBERS AND LOCATIONS .....</b>	<b>4-2</b>
<b>FIGURE 4-2: STEP-LIFT ASSEMBLY .....</b>	<b>4-4</b>
<b>FIGURE 4-3: SAFETREAD .....</b>	<b>4-6</b>
<b>FIGURE 4-4: PLATFORM-TO-SADDLE ASSEMBLY (SHEET 1) .....</b>	<b>4-8</b>
<b>FIGURE 4-5: PLATFORM-TO-SADDLE ASSEMBLY (SHEET 2) .....</b>	<b>4-10</b>
<b>FIGURE 4-6: FRAME AND SADDLE ASSEMBLY .....</b>	<b>4-12</b>
<b>FIGURE 4-7: PUMP BOX ASSEMBLY .....</b>	<b>4-14</b>
<b>FIGURE 4-8: PUMP &amp; PUMP PLATE ASSEMBLY .....</b>	<b>4-16</b>
<b>APPENDIX 1: STEP-LIFT SPECIFICATIONS .....</b>	<b>4-18</b>

This page intentionally left blank.