



*Innovation in Mobility*

**RD02900 Series  
Internal Power  
Swing Door Operator**

[TABLE OF CONTENTS](#)

[Print Entire Manual \(350K\)](#)

**Operator Manual**

**This RICON product must be installed and serviced by authorized RICON service technicians.**

**The operator must refer to this manual for operating instructions, then retain it for future reference.**

Customer Name: \_\_\_\_\_  
Installing Dealer: \_\_\_\_\_  
Date Installed: \_\_\_\_\_  
Serial Number: \_\_\_\_\_

## REVISION RECORD

REV	PAGES	DESCRIPTION OF CHANGE	ECR/ECO
32DD005. A	All	New release, in two-book format.	3882/4864
END OF LIST			

## TABLE OF CONTENTS

---

<i>Chapter:</i>	<i>Page</i>
<b>I. INTRODUCTION</b> .....	<b>1-1</b>
A. RICON ONE-YEAR LIMITED WARRANTY .....	1-1
B. SHIPMENT INFORMATION .....	1-3
C. GENERAL SAFETY PRECAUTIONS .....	1-3
D. PRODUCT TERMINOLOGY .....	1-4
<b>II. OPERATING INSTRUCTIONS</b> .....	<b>2-1</b>
A. SAFETY PRECAUTIONS .....	2-1
B. DAILY SAFETY CHECK .....	2-2
C. CONTROLS AND INDICATORS .....	2-2
1. LIFT OR RAMP CONTROL PENDANT .....	2-2
2. ELECTRICAL CONTROLS AND INDICATORS .....	2-3
D. POWER DOOR OPERATION .....	2-5
1. TO ENTER VEHICLE .....	2-5
2. TO EXIT VEHICLE .....	2-6
3. MANUAL OPERATION .....	2-6
<b>III. MAINTENANCE</b> .....	<b>3-1</b>
A. MAINTENANCE INFORMATION .....	3-1
B. MAINTENANCE SCHEDULE .....	3-1
C. TROUBLESHOOTING GUIDE .....	3-2
D. LIFT DECALS .....	3-4



[TO NEXT CHAPTER](#)