



## INSTALLATION INSTRUCTIONS NEW PENDANT MOUNTING CLIP KIT # 14709


- Be certain that these supplemental instructions are read and understood completely before installation is attempted. You should also refer to the Service/Owner Manual for additional installation instructions and safety precautions.
- Check contents of this kit and notify Ricon immediately of any missing parts. Claims for damages that have occurred during shipping must be made to the shipper.

### I. INSTALLATION

#### A. DESCRIPTION

All Ricon Control Pendants are shipped with a metal Pendant Clip (male) attached to the back of the pendant at the factory. The pendant can be mounted remotely from the lift, using the enclosed metal Pendant Mounting Bracket per the following instructions.

 <b>WARNING!</b>
LOCATE THE PENDANT MOUNTING BRACKET SO THAT THE ATTENDANT WILL BE SAFELY CLEAR OF MOVING PLATFORM WHILE OPERATING THE LIFT.



**FIG.1: PENDANT MOUNTING DIAGRAM**

1. Refer to **Figure 1**. Fasten the pendant mounting bracket, wide end up, to a hard flat surface using the enclosed screws.
2. Install pendant at remote location by sliding pendant mount into top of pendant mounting bracket.