

# INSTALLATION INSTRUCTIONS S-SERIES™ OUTER ROLLSTOP REPLACEMENT KIT # 01221/01222/01223

- Read and understand supplemental instructions completely before installation is attempted. Refer to the Service/Owner Manual for additional installation instructions and safety precautions.
- Check contents of kit. Immediately notify Ricon of any missing parts. Claims for damages that have occurred during shipment must be made to the shipper.

| TABLE OF CONTENTS |                                    |                           |             | PAGE |  |  |
|-------------------|------------------------------------|---------------------------|-------------|------|--|--|
| l.                | TOOLS REQUIRED                     |                           |             | 1    |  |  |
| II.               | INTRODUCTION                       |                           |             | ′    |  |  |
| III.              | DISASSEMBLY PROCEDURE              |                           |             | 1    |  |  |
| IV.               | ASSEMBLY PROCEDURE                 |                           |             | 2    |  |  |
| I.                | TOOLS REQUIRED                     |                           |             |      |  |  |
|                   | 5/16 Socket head<br>Loc-Tite® Blue | Hex key set<br>Red grease | 7/16 Wrench |      |  |  |

# II. INTRODUCTION

The following instructions outline the installation of an outer Rollstop Retrofit kit on any S-Series™ lift

**NOTE:** Refer to **Figure [1]** and its parts list (pages 3 and 4).

## III. DISASSEMBLY PROCEDURE

A. REFER TO FIGURE [1]. REMOVE ITEM #1 BY REMOVING ITEMS: #12, #21 AND #25.

## B. REMOVE ITEMS #4 AND #5 BY:

- 1. Removing 4 set screws item #26.
- 2. Remove two springs (items #6A and #6B).
- 3. Remove item #13 from the platform.

# IV. ASSEMBLY PROCEDURE

#### A. IF ITEM #24 IS 31", 33" OR 40.5" INCHES WIDE:

- 1. Install items #4 and #5 per following:
  - a. Insert item #13 into the platform.
  - b. Insert 2 Ea. of item #23 onto items #4 and #5 and insert both through item #13 into the platform.
  - c. Place item #8 in between both pieces (#4 and #5) and by using the four cup setscrews install them. Use Loc-Tite® Blue for setscrews.

**NOTE:** Be sure items# 4 and #5 are inserted completely.

- d. Install the springs; items#6A and #6B on both sides. It is recommended to connect the springs to the frame first and then to the arms.
- 2. Connect item #1 to items#4and #5 per following:
  - a. Insert items #12 and #29 and attach them to item #20 through items #4 and #5.
  - b. Insert items #21 (new supplied item) and by using the cone setscrews (items #25). Tighten the assembly. There will be a gap between the end of the pin and the rollstop, this is normal. Use Loc-Tite® Blue for setscrews.

**NOTE:** Spacers (item #11) is not used.

## B. IF ITEM #24 IS 30.5", 32.5" OR 40" INCHES WIDE:

- 1. Install items # 4 and #5 per following:
  - a. Insert item #13 into the platform.
  - b. Install 3 Ea. of item#23 onto items#4 and #5 and insert both through item #13 into the platform.
  - c. Place and install item #8 in between both pieces (4 and 5) using four cup setscrews. Use Loc-Tite® Blue for setscrews.
  - d. Install springs (items #6A & #6B) on both sides. (It is recommended to connect the springs to the frame first and then to the arms.)
- 2. Connect item #1 to items #4 & #5 per following:
  - a. Insert items #12 and #29 and attach them to item #20 through items #4and #5.
  - b. Install items #21 and #11 (new supplied item) by inserting the cone setscrews (items# 25). Tighten the assembly (use Loc-Tite® Blue for setscrews).

**NOTE:** Use red grease on all the necessary locations.

c. Peel off and apply item #27 on top of item #1.




FIGURE [1]

# FIGURE [1] PARTS LIST:

| ITEM# | DESCRIPTION   | QTY |
|-------|---|-----|
| 1     | Platform Roll Stop (different length)                 | 1   |
| 4     | Rollstop Actuator, Weld Assy. L.H. (different length) | 1   |
| 5     | Rollstop Actuator , Weld Assy. R.H. (different length | 1   |
| 6A    | Spring, Torsion, R.H.                                 | 1   |
| 6B    | Spring , Torsion, L.H.                                | 1   |
| 8     | Collar, Rollstop Actuator, Connector                  | 1   |
| 11    | Bushing , Steel                                       | 2   |
| 12    | "T" Nut, Stainless                                    | 2   |
| 13    | Bearing Rollstop Actuator Shoe                        | 2   |
| 20    | Cap Screw , Hex Head, 1/4-20X1/2"                     | 2   |
| 21    | Pin., Outer Barrier Clevis                            | 2   |
| 23    | Washer, 3/8" SAE                                      | 6   |
| 24    | Platform Frame  | 1   |
| 25    | Screw, Socket Set, Cone Point, 1/4-20X1/4             | 2   |
| 26    | Screw, Socket Set, Cup Point , 1/4-20X1/4             | 4   |
| 27    | Matting, Non Slip                                     | 4   |
| 29    | Washer, Nylon, .318 ID X .751 OD X .031               | 4   |